


## Splitboard Heel Lock Retrofit Kit



- Simple and effective heel locking device for use with Dual Height Climbing Heels.
- Compatible with Speed Rail, Light Rail and Slider Track.
- Use for short descents in rolling terrain, traversing ridgelines, and sidestepping.











## Installation:



1.) Thread each pull-cord end through the holes on the pull-tab at the rear of the Heel Lock.



3.) Remove all hardware from the heel inserts on both board halves. Blow out the inserts to clear them of any debris. Existing screws will be reused.



**5.)** Position your Climbing Block and Climbing Wires over the inserts with the longer 75mm wire facing the board's tip. Fasten screws securely.



2.) With the pull-cord tags equal lengths, tie a simple over-hand knot at the end of the cord



4.) Position the Guide Washer over the inserts with the flat side facing the board's topsheet. Place the Heel Lock over the Guide Washer with the pull cord pointed towards the tail of your board.



6.) To lock your heel: Lower both climbing wires, rotate your binding down to rest flat against the board, and slide the Heel Lock forward

